

Figure 1A




Figure 1B




Figure 2




Figure 3A

| Item | Description |
|--------------------------|--|
| Job Builder: | |
| Build | Initiates building of new job |
| Save | Save the job information. |
| Save As | Functions conventionally |
| Open | Functions conventionally |
| Close | Functions conventionally |
| Job Information | Functions conventionally |
| Site Tools: | |
| Add Tool to Process | Inserts selected tool into process |
| Remove Tool from Process | removes selected tool from process |
| Available Tools | Displays tools available for processes |
| Tool Description | Brief description of tool |
| Site Process | Displays process (recipe) as it is being constructed by user |

Figure 3B

| |
|---|
| Available Tools: Grab Image Pattern Beam Coincidence Pause |
| Tool Description: Will make both beams point at the same spot needed for imaging while milling. |
| Site Process: Grab Image Pause |

Figure 3C

| Job Wafer Data Input | |
|---|-------------|
| Operator ID: | W. Bee |
| Defect File: | fei.rft |
| Lot ID: | 060265 |
| Wafer ID: | 01 |
| Job File: | TestJob.dar |
| Product: | Train Align |
| <input type="checkbox"/> Unload Wafer when Job Complete | |
| Run | Cancel |

Figure 3D




Figure 3E




Figure 3F

| Interface Items | Description |
|----------------------------|---|
| Filter Name | Identifies the filter. |
| Filter Criteria | These check boxes and list boxes select the filter criteria. |
| New | Creates a new filter file. |
| Open | Opens an existing filter. |
| Save | Saves the edited filter definition. It is available only if allowed by configuration. |
| Save As | Saves the edited filter definition to a new file name. It is available only if allowed by configuration. |
| Random Subset | Specifies the maximum number of random sites passing the filter. |
| Test Results | Tests and reports the effect of site filter changes. |
| Temporarily Disable Filter | Temporarily disables the active site filter. |
| Graph | Displays a histogram of the defect sites. |
| Class List | Opens the Edit Class List dialog box. |
| Undo | Undoes the last change. You cannot undo changes already saved to file. |
| Undo All+ | Undoes all changes made since dialog box opened. You cannot undo changes already saved to file. |
| Close | Closes the dialog box. Applies the defined filter to the current review session but does not save the filter to file. |

Figure 3G

| Criterion | Value Type | Description |
|--------------------------|------------|--|
| Classification | Integer | Classification code assigned to the site |
| Size X (μm) | Real | X dimension of the site in microns |
| Size Y (μm) | Real | Y dimension of the site in microns |
| Die Column | Integer | Die column of the die containing the site |
| Die Row | Integer | Die row of the die containing the site |
| SLI | Integer | Scattered light intensity reported for the site |
| Visited | Yes/No | Site has or has not been visited during the review session |
| Modified | Yes/No | Site has or has not been classified or relocated during the review session |
| ADE Channel | Light/Dark | Select sites from either the light or the dark channel. |
| SP1 Channel | n/a | Site has selected attributes. This filter is active if the defect format is T7x00 and the defect file has more than one channel. |
| Has Image | Yes/No | Site has or does not have image data associated with it |

Figure 3H

| Relational Operators | Meaning |
|----------------------|--------------------------|
| = | Equal to |
| != | Not equal to |
| < | Less than |
| <= | Less than or equal to |
| > | Greater than |
| >= | Greater than or equal to |

Figure 3I

7 / 50

Random Subset

☒ Enable Random Subset

50 Percent

Percent

Maximum

Figure 3J

Test Results

Apply Now

Total Sites 68

Filtered Out 0

Remaining 68

Figure 3K

Defect File fe12.001

Wafer ID @05

Lot ID K54148350

Process ID 814FC

68 Total Sites, 68 Passing Filter

Figure 3L

☒ Temporarily Disable Filter

Figure 3M

| Defect # | Size X | Size Y | Classification Recipe Name | Die Row |
|----------|--------|--------|----------------------------|---------|
| | | | | |
| | | | | |

Figure 3N




Figure 30




Figure 3P





| Control | Description | Behavior |
|---|---|--|
|  | Product/Step Tree View: This is the interface through which specific Steps are created, edited, and deleted. | Sorting: Alphabetized by Product, then by Step. Node Behavior: Expandable and Collapsible through a standard interface. Persist Expansions for the life of the dialogue. Scroll Bars: Scrolling should be allowed. |
|  | New Product Button: This is used to add a New Product to the Database. | Click: This should launch a "New Product Wizard" which is described below. |
|  | New Step Button: This is used to add a New Step to whichever product is selected in the Product/Step Tree View (above). | Enable/Disable: Enable if a Product has been selected. Disabled otherwise. Click: This should launch the "New Step Wizard" which is described below. |
|  | Delete Button: This is used to remove products or steps from the database. | Click: This should launch a standard two-button dialogue with the message "Permanently Delete [Product/Step] Information?". The buttons are "Cancel" and "OK". |

Figure 3Q




Figure 3R

Figure 3S







| Control | Description | Behavior |
|---|--|--|
|  | Site Sequence List Tree View: This displays a list of Site Sequences which can be expanded to show the names of the tools. | <p>Scrolling: Should be scrollable.</p> <p>Node Behavior: Expanded nodes should stay expanded.</p> <p>Alphabetized.</p> <p>Click: This should highlight the site sequence.</p> <p>Default selection: The first site sequence in the list should be highlighted by default.</p> <p>Double-Click: This should expand the node to display the list of tools within the site sequence.</p> <p>Mouse Over: This should display the Site Sequence Name followed by the text description of the site sequence (if any).</p> |
|  | Edit Button: This loads the site sequence into the Recipe Builder page. | <p>(Optionally) the page display should be switched to the Recipe Builder.</p> <p>Click: Load the selected site sequence into the recipe builder page</p> |
|  | View Info Button: THIS BUTTON HAS BEEN REMOVED. | NOT APPLICABLE. (The tree view functionality eliminates the previously envisioned function of this button). |
|  | Delete Button: This button removes the site sequence from the database. | Click: This removes the site sequence from the database as far as the user is concerned. The actual implementation should include an "Is Deleted" flag to indicate that the site sequence should not be displayed. This will prevent previously configured processes from being invalidated. |
|  | Site Filter Text Box: This shows a list of all Site Filters available for the selected Product/Step in the Product/Step Tree View control (above). | <p>Alphabetize.</p> <p>Click: Highlight the site filter.</p> <p>Default Selection: The first of the list should be highlighted by default.</p> |
|  | Edit Button: This is used to edit the highlighted site filter. | Click: Launch the site filter dialog for the highlighted site filter. |

Figure 3T




Figure 3U

| Recorder Site Plans Site Maps Alignment Data HIDE REDUCE EXPLODER | | | | | | | | | |
|--|---------|---------|---------|---------|---------|---------|---------|---------|---------|
| LINE | STATION | STATION | STATION | STATION | STATION | STATION | STATION | STATION | STATION |
| 1 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 |
| 2 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 |
| 3 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 |
| 4 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 |
| 5 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 |
| 6 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 |
| 7 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 |
| 8 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 |
| 9 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 |
| 10 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 | 0+00 |

Figure 3X





| Control | Description | Behavior |
|---|---|--|
|  | Alignment Data Tree View. This is a tree view showing the Alignment data in the following order. | Node coloring: The nodes should be colored red if they or a child is untrained. Data Structure: A preliminary data structure for this tree is shown and described in the following section. |
|  | Test Button. If appropriate, this should test the selected alignment on the wafer loaded into the system. | Enable/Disable: This is dependant on the highlight node of the Alignment Data Tree View. For certain alignments test functionality will not be appropriate and should not, therefore, be applied. Click: Run the alignment for the highlighted node and all child nodes in the Alignment Data Tree View. |
|  | Train Button. If appropriate, this should initiate the portion of the Alignment Training Wizard for the selected node. | Enable/Disable: For some nodes this control may not make sense or may require functionality not provided by the software. In these situations the control should be either disabled or handled through a clear, concise error message. For example, training the zero degree alignments for a wafer loaded at 52 degrees might prompt the user to tilt to zero degrees and try the alignment again. Click: Run the portion(s) of the alignment training wizard for the highlighted node and child nodes. Note that there may be unanticipated exceptions that need to be dealt with (such as no wafer is loaded) that will require increased robustness in the handling of errors and exceptions. These will be ferreted out at a later time. |
|  | Delete Button: This <i>permanently</i> deletes alignment data from the database. | Click: This should launch a standard two button dialogue with the message "This will |

Figure 3V






| Control | Description | Behavior |
|---|---|----------|
|  | | |
|  | Recipe Tab. This should have the following fields. <ul style="list-style-type: none"> ○ Product ○ Step ○ Recipe Name ○ Creation Date | |
|  | Site Filter Tab. This should have the fields listed below. As an added feature, there could be a "view filter button" to allow a quick look at the data through a new window. <ul style="list-style-type: none"> ○ Product ○ Step ○ Site Filter Name ○ Creation Date | |
|  | Site Map Tab. This should have the fields listed below. As an added feature, there could be a "view filter button" to allow a quick look at the data in a new window (similar to above). <ul style="list-style-type: none"> ○ Product ○ Step ○ Site Map Name ○ Creation Date | |
|  | Alignments Tab. This is a complex control, but the should have the fields listed below. Alignment Node should be a path which indicates where the alignment data exists on a tree structure identical to that described above. <ul style="list-style-type: none"> ○ Product | |

Figure 3Y

- ❖ Alignment Name # 1
 - Wafer Alignment
 - Product Offset
 - Zero Degrees
 - Alignment Dies
 - Top-Down Electron Beam Image
 - Ion Beam Image
 - Fifty-Two Degrees
 - Alignment Dies
 - Ion Beam Image
 - Electron Beam Image
 - System Calibrations
 - Height Probe Offset
 - Zero Degrees
 - Fifty-Two Degrees
- ❖ Alignment Name # 2

...

Figure 3Z




Figure 4A

| Item | Description |
|--------------|--|
| Run | Loads the wafer and runs the selected job. |
| Pause | Pause job execution |
| Abort | Terminate job execution |
| Description | Comment text describing job if included in job |
| Site Process | Displays job process tools |

Figure 4B




Figure 4C

Job Wafer Data Input

Operator ID: ...

Defect File: ...

Lot ID: ...

Wafer ID: ...

Job File: ...

Product: ...

☒ Unload Wafer when Job Complete

Figure 4D

| Interface Item | Description |
|--------------------------------|---|
| Operator ID | Required field where the user enters name. |
| Defect File | Defect file for the job. User opens an existing defect file. Clicking the select button opens the Select Defect File dialog box. |
| Lot ID | Maximum of 15 characters. Value is read in from defect file or job file, selected from dialog box, or entered by the operator. |
| Wafer ID | Maximum of 5 characters. Value is read in from defect file or job file, selected from dialog box, or entered by the operator. |
| Job File | Selects a recipe or job file. The recipe contains no wafer information. The job file contains wafer information. They have different extensions, .daj and .dar. |
| Product | Identifies the alignment wizard for the wafer. If TRAIN ALIGN is selected, when the user clicks RUN, the Alignment Training wizard starts. |
| Cass A/B | Shows the slots that are occupied. |
| Inventory | Inventories the cassettes. |
| FlexiLock | Shows if wafer is in the cassette. |
| Unload wafer when job complete | Provides automated wafer unloading when a job is complete. |
| RUN | Dialog box closes and the Information dialog box displays. When user clicks OK in Information dialog box the sequencer runs the job. This button is not active until information for at least one wafer is entered. |
| Cancel | Dialog box closes without saving the values. In job builder, the dialog box closes and the Add Tool interface displays. In sequencer, a warning box displays so that the user does not unintentional lose information. Then, the Sequencer page becomes active again. |
| Select button | Opens dialog where predefined files, wafers, etc., can be selected. |

Figure 4E

Job Wafer Data Input

Operator ID: ...

Defect File: ...

Lot ID: ...

Wafer ID: ...

Job File: ...

Product: ...

Cass A

| |
|----|
| 2 |
| 4 |
| 5 |
| 6 |
| 7 |
| 8 |
| 9 |
| 10 |
| 11 |
| 12 |
| 13 |
| 14 |
| 17 |
| 18 |
| 21 |
| 23 |
| 24 |
| 25 |

Cass B

| |
|----|
| 3 |
| 4 |
| 5 |
| 9 |
| 13 |
| 16 |
| 17 |
| 18 |
| 19 |
| 20 |
| 22 |
| 24 |
| 25 |

Inventory

Figure 4F

Job Wafer Data Input

Operator ID: ...

Defect File: ...

Lot ID: ...

Wafer ID: ...

Job File: ...

Product: ...

Cass A

| |
|----|
| 2 |
| 4 |
| 5 |
| 7 |
| 8 |
| 10 |
| 11 |
| 12 |
| 13 |
| 14 |
| 17 |
| 18 |
| 19 |
| 22 |
| 23 |
| 24 |
| 25 |

Cass B

| |
|----|
| 3 |
| 4 |
| 5 |
| 6 |
| 7 |
| 8 |
| 9 |
| 11 |
| 12 |
| 13 |
| 14 |
| 15 |
| 17 |
| 19 |
| 20 |
| 22 |
| 23 |
| 24 |
| 25 |

Inventory

FlexiLock

Figure 4G




Figure 4H




Figure 4I

| Defect File Contents | | |
|----------------------|------------|------------|
| Wafer ID | Inspection | Site Count |

Figure 4J

| Column Header | Description |
|---------------|--|
| Wafer ID | The wafer ID as listed in the defect file. |
| Inspection | The date and time the site list was created during inspection. |
| Site Count | The number of defect sites in the site list. |

Figure 4K




Figure 4L




Figure 4M





Figure 4N

**Figure 5**

FEI Defect Explorer

Search Criteria:

Select
Lot ID Wafer ID

Job Start Date Job End Date

Quick Search

Job Details:

| <input checked="" type="checkbox"/> Job name | | |
|--|--|--|
| <input checked="" type="checkbox"/> Job name | | |
| <input checked="" type="checkbox"/> Job name | | |
| <input checked="" type="checkbox"/> Job name | | |
| <input checked="" type="checkbox"/> Job name | | |
| <input checked="" type="checkbox"/> Job name | | |
| <input checked="" type="checkbox"/> Job name | | |

Figure 6A

FEI Defect Explorer

Water Details

Water: Water:

☒ Show Water History

Water Map

Image

Thumb Nail Images of Site: xxxxx

| | | |
|--|--|--|
| | | |
| | | |

Site Comments

Figure 6B

FBI Defect Explorer

View Details of Jobs
Selected For Delete

View Details
Selected For
Export

View Site Details
Tagged For Revisit

View Details of
Images Selected
For Delete

Details:

| | | |
|--|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Delete Job

Export

Tag for ReVisit

Delete Images

< Back

Sign Out

Figure 6C




Figure 7A




Figure 7B




Figure 8A

| Item | Description |
|----------------------|---|
| Realign: | |
| Beam | Specifies the beam to be used in the alignment. |
| Type | Specifies measurement or the type of alignment. BEAM SHIFT specifies an alignment using beam shift. MEASURE instructs the system to measure the X, Y distance between the center of the image and the center of the fiducial mark, in pixels and microns. The result is written to the user-specified log file. STAGE MOVE specifies an alignment using a stage move. |
| Assist Timeout | Number of seconds a dialog box remains on screen, prompting for user intervention. If this value is 0, no dialog box appears. |
| Display Match Dialog | Displays the Image Match dialog box (see Image Match). |
| Suppress Errors | When this option is selected, the system ignores image recognition errors. If ENABLE LOGGING is selected, image recognition errors are written to the user-specified log file. |
| Offsets: | |
| Field of View | Specifies a proportional shift of the field of view. When this option is selected, the system shifts the field of view by the proportion of the field of view specified in X and Y. When this option is not selected, the system shifts the field of view by the distance in microns specified in X and Y. |
| X, Y | Specify the distance by which the system shifts the field of view during alignment. When FIELD OF VIEW is selected, the values specified in X and Y denote a portion of the field of view—e.g., a value of 0.1 equals 10% of the field of view. In one embodiment, acceptable values are 0–1. When FIELD OF VIEW is not selected, the system shifts the field of view by the distance in microns specified in X and Y. |
| Logging: | |
| Enable Logging | When this option is selected and a log file is specified, the system logs the following information: Name and path of the image file used for realignment X location of the fiducial in pixels and microns Y location of the fiducial in pixels and microns When MEASURE is selected for TYPE, the X, Y distance between the center of the image and the center of the fiducial mark, in pixels and microns. If the fiducial is not found, the system writes "Fail" to the log file. |
| Log File | Name and path of the specified log file. Use the adjacent Browse button to navigate to the desired directory. |

Figure 8B




Figure 8C




Figure 8D

Cross Section Settings

| | | |
|---|---|---|
| <p>Deposition:</p> <p>Material File <input type="text" value="pt_high.mtr"/></p> <p>Width <input type="text" value="10.00"/> %</p> <p>Height <input type="text" value="10.00"/> %</p> <p>Depth <input type="text" value="0.50"/> μm</p> | <p>Bulk Mill:</p> <p>Material File <input type="text" value="si.mtr"/></p> <p>Width <input type="text" value="10.00"/> %</p> <p># of Cuts <input type="text" value="5"/></p> <p>Maximum Total Time (Bulk Mill & Cross Section) <input type="text" value="20.00"/> Seconds</p> | <p>Cross Section:</p> <p>Material File <input type="text" value="si.mtr"/></p> <p>Width <input type="text" value="10.00"/> %</p> <p>Height <input type="text" value="10.00"/> %</p> <p>Depth <input type="text" value="0.50"/> μm</p> |
|---|---|---|

Current Offset: μm

Figure 9A

| Item | Description |
|-----------------------|--|
| Deposition: | |
| Material File | Displays a dropdown menu for selecting a material file (.mtr). The list contains an entry for every material file available on the system. |
| Width | Width of the specified cross section (X), as a percentage of the field of view. |
| Height | Height of the specified cross section (Y), as a percentage of the field of view. The protective coat will be centered about the location of the cross-section target line. |
| Depth | Depth of the specified cross section, in microns. |
| Bulk Mill: | |
| Number of Cuts | Number of cuts to be made in the bulk mill. |
| Cross Section: | |
| Maximum Total Time | As in Deposition group, above. |
| | Sets the total pattern time for the bulk mill and cross-section patterning. Defect Analyzer uses this value to select the apertures used for bulk milling and cross-sectioning, based on the specified pattern area, depth, and material file. |
| Y Offset | Displays a horizontal yellow line in the image quadrant, marking the desired upper boundary of the cross section. Click anywhere in the field of view to set the location of this yellow line, then click OK in the accompanying dialog box. For further information, see "Setting Y Offset" on page 4-14. |

Figure 9B

Fiducial Tool Configuration

| | Low | Med | High | Bitmap: |
|------|-------|-------|-------|---------|
| Fast | 0.028 | 0.091 | 0.362 | |
| - | 0.045 | 0.181 | 0.724 | |
| - | 0.136 | 0.543 | 2.173 | |
| Slow | 0.396 | 1.584 | 6.337 | |

Integrate:

Size (% FOV): Defect: Fiducial:

Fiducial Offset From Center (% FOV):
 X: Y:

GIS: Depth:

Figure 10A

| Item | Description |
|--|---|
| Scan speed matrix | Sets the frame time and resolution used in ion beam and electron beam images collected after milling of the fiducial mark. These images are used for subsequent image recognition. |
| Integrate | Sets the number of frames to be integrated to allow accumulative noise reduction. |
| Bitmap | Defect Analyzer converts the specified bitmap to a stream file, based on the grayscale levels of individual pixels in the bitmap. Pixels above the median brightness in the grayscale are omitted from the stream file; pixels below the median brightness are converted to points. |
| Size (%FOV) | |
| Defect | Proportion of the field of view to be occupied by the defect. |
| Fiducial | Size of the fiducial mark, as a percentage of the field of view. |
| Fiducial Offset From Center (%FOV) | Sets the offset between the center of the image and the center of the fiducial mark, in X and Y, as a percentage of the field of view. |
| GIS | Selects the GIS to be used in milling the fiducial. The list contains an entry for every beam chemistry available on the system. |
| Depth | Depth of the fiducial mark, in microns. |
| Configure EBeam Realign | |
| Configure IBeam Realign | |
| Configure IBeam BMP Realign, Configure EBeam BMP Realign | CONFIGURE EBEAM BMP REALIGN and CONFIGURE IBEAM BMP REALIGN configure the image recognition software for initial matches between a fiducial mark and the bitmap used as the milling pattern. |

Figure 10B




Figure 10C




Figure 10D




Figure 10E




Figure 10F




Figure 10G




Figure 10H

Beam: **Electron**

Realign Using Beam Shift: **Yes**

Enable Logging: **No**

Display Match Dialog: **No**

Assist Timeout (s): **0**

☐ FOV Offsets

X Offset: **0.000000**


Y Offset: **0.000000**

Apply **Cancel**

Figure 11A


| Item | Description |
|--------------------------|---|
| Beam | Specifies the beam to be used in the alignment. |
| Realign Using Beam Shift | Specifies the type of alignment to be made. YES specifies an alignment made using beam shift. NO specifies an alignment made using a stage move. For best results, realign the electron beam with stage moves and the ion beam with beam shift. |
| Enable Logging | When this option is selected, the system logs the following information: Name and path of the image file used for realignment X location of the fiducial in pixels and microns Y location of the fiducial in pixels and microns If the fiducial is not found, the system writes "Fail" to the log file. |
| Display Match Dialog | Displays the Image Match dialog box (see "Image Match" on page 4-10). |
| Assist Timeout(s) | Number of seconds before a dialog box appears, prompting for user intervention. If this value is 0, no dialog box appears. |
| FOV Offset | Specifies a proportional shift of the field of view. When this option is selected, the system shifts the field of view by the proportion of the field of view specified in X and Y. When this option is not selected, the system shifts the field of view by the distance in microns specified in X and Y. |
| X Offset, Y Offset | Specify the distance by which the system shifts the field of view during alignment. When FIELD OF VIEW is selected, the values specified in X and Y denote a portion of the field of view—e.g., a value of 0.1 equals 10% of the field of view. Acceptable values are 0–1. When FIELD OF VIEW is not selected, the system shifts the field of view by the distance in microns specified in X and Y. |

Figure 11B

**Figure 12A**

| Item | Description |
|-----------|---|
| Auto CB | Performs automatic contrast and brightness. |
| Spot Mode | Selects Spot as the scanning mode. |
| Voltage | Voltage to be used to acquire spectrum. |

Figure 12B

**Figure 12C**

| Interface items | Description |
|-----------------|--|
| Resume | Associates the spectrum with the current site and continues automated processing. |
| Cancel | Does not put anything into the database and gives you the option to fail the site. |

Figure 12D

Get System Settings

Set Settings Tool Identifier

☒ A

☐ B

☐ C

☐ D

☐ E

☐ F

Stage

☐ X Y

☐ Z

☐ R

☐ T

Select All

Beam Settings

☐ Primary Beam

☐ Detector

☐ Scan Rotation

Electron Beam

☐ Focus
☐ Stig
☐ kV
☐ Spot
☐ Electron Beam Shift
☐ UHR/Search
☐ Magnification
☐ Contrast/Brightness

Ion Beam

☐ Focus
☐ Stig
☐ Ion Aperture
☐ Ion Beam Shift
☐ Magnification
☐ Contrast/Brightness

Apply

Cancel

Figure 13A

| Item | Description |
|------------------------------|--|
| Select All/De-Select All | Selects or deselects every option in the Stage, Beam Settings, Electron Beam, and Ion Beam groups. |
| Set Settings Tool Identifier | Identifies a set of stored settings. |
| Stage | Contains options for recording the positions of the five independent axes. |
| Beam Settings | Contains options for recording the following current beam settings: |
| Primary Beam | |
| Detector | |
| Scan Rotation | |
| Electron Beam | Contains options for recording the current electron beam parameters: Focus, Stigmation, Accelerating voltage (kV), Spot size, Beam shift, Mode (UHR or Search), Magnification, Contrast/Brightness |
| Ion Beam | Contains options for recording the current electron beam parameters: Focus, Stigmation, Aperture, Beam shift, Magnification, Contrast/Brightness |

Figure 13B

Grab Image Settings

☒ E-Beam ☐ I-Beam

Electron Settings

Voltage (kV) Spot Size

Detector

☒ TLD-S

☐ TLD-B

☐ TLD-C

☐ TLD-D

☐ CDM-E

☐ CDM-I

Mode

☐ UHR

☒ Search

Image

☐ ACB

☐ AutoFocus

☐ AutoStig

☒ Data Bar

Magnification

☒ Field of View

☐ Fixed

Ion Settings

Aperture

Resolution

| | Low | Med | High |
|------|-------|-------|-------|
| Fast | 0.028 | 0.091 | 0.362 |
| - | 0.045 | 0.181 | 0.724 |
| - | 0.136 | 0.543 | 2.173 |
| Slow | 0.396 | 1.584 | 6.337 |

Integrate

Figure 13C

| Item | Description |
|---------------------------|---|
| E-Beam | Use electron beam to grab an image. |
| I-Beam | Use ion beam to grab an image. |
| Electron Settings: | |
| Voltage (kV) | Active only for the electron beam. Specify the accelerating voltage. |
| Spot Size | Active only for the electron beam. Specify the spot size. |
| Detector | Select the detector used to collect the image. Available selections are dependent on the selected mode and beam. Refer to the xP DualBeam Workstation User's Guide (PN 25417) for information about detector types. |
| Mode | Active only for the electron beam. Select Search mode for low magnifications and UHR mode for higher magnifications. |
| Image: | |
| ACB | Automatically adjusts contrast and brightness using the stored values for comparison. |
| AutoFocus | Automatically corrects the focus, based on the system sharpness criteria. |
| AutoStig | Automatically corrects stigmatism, based on the system sharpness criteria. Available for the electron beam. |
| Data Bar | Save the databar as seen into the image. |
| Magnification | Specifies the magnification used to grab the image. Select either the field-of-view (determined by the Fiducial tool) or choose from a range of preset magnifications. |
| Ion Aperture | Active only for the ion beam. Sets the ion aperture. |
| Resolution | Selects the scan rate and resolution for grabbing a single frame. The values are those available for Grab Image. |
| Integrate | Specifies the number of collected images to be summed to generate the final image. |

Figure 13D

Pattern Settings

☐ Use FOV %

Overlap
 %

Primary Beam
☒ I-Beam ☐ E-Beam

Dimensions
 X: μm
 Y: μm
 Z: μm

Dwell
 μs

Material File

Center Position
 X: μm
 Y: μm

Time

 hh:mm:ss

Pattern Type

☐ Always Realign

Rotation
 Degrees

Figure 14A

| Item | Description |
|------------------------------|--|
| Use FOV % | Converts X and Y coordinates in Dimensions and Center Position to a percentage of the field of view. When this option is selected, X and Y coordinates in Dimensions and Center Position denote a percentage of the field of view. When this option is not selected, X and Y coordinates in Dimensions and Center Position are in microns. |
| Dimensions | Sets the X, Y, and Z pattern dimensions. When Pattern Type is set to Circle, X and Y are replaced by Rin (inner radius) and Rout (outer radius). |
| Center Position | Shows the stage X and Y coordinates of the center of the pattern relative to the center of the field of view. |
| Overlap | Beam overlap. Not available when a material file is selected. |
| Dwell | Dwell time per pixel. Not available when a material file is selected. |
| Time | Time for milling displayed as either hh:mm:ss or ss:tt. |
| Always Realign | When this option is selected, the system always realigns to the fiducial mark before milling the specified pattern. When this option is selected, the system only realigns to the fiducial mark when an aperture has changed or a GIS needle has been inserted. |
| Show Pattern/ Remove Pattern | Displays the currently defined pattern. When a pattern is already on screen, removes that pattern. |
| Primary Beam | Select I-BEAM or E-BEAM as the beam that will be used for patterning. |
| Material File | Select the material file for your application. Refer to the xP DualBeam Workstation User's Guide (PN 25417) for information about material files. |
| Pattern Type | Defines the pattern. Refer to the xP DualBeam Workstation User's Guide (PN 25417) for information about available patterns. |
| Rotation | Rotates the pattern about its center to the specified angle. |

Figure 14B




Figure 15A

| Item | Description |
|---------------|--|
| Message area | Defines actions the user should take before continuing processing. |
| Audible alarm | Causes an alarm to sound when the Pause dialog box displays during a job. |
| Auto dismiss | Selects if the Pause dialog box should time out. Otherwise, the Pause dialog box must be manually dismissed. The number of seconds specifies the fixed amount of time Pause dialog box is displayed during a job. |

Figure 15B




Figure 15C

| Item | Description |
|---------------|---|
| Message area | Defines action operator should take before proceeding with the process. The text cannot be modified during runtime. |
| Timeout clock | The time the dialog box will be displayed during a job. If the operator does not interact with the tool, the Pause dialog box times out as specified and the process automatically continues. |
| Continue | Click to continue processing the current site. The site list grid will show that the site passed. |
| Pause/Resume | Stops/restarts the timer. (This button is inactive if AUTO DISMISS was not selected during configuration.) The process waits for the operator to click either CONTINUE or FAIL. |
| Fail Site | Click to fail the current site. Further processing at the site is aborted. Processing starts at the next site. The site list grid will show that the site failed. If the entire job is to be aborted, the operator can click ABORT in the Run Tool Sequence dialog box. |

Figure 15D




Figure 16




Figure 17A

| Item | Description |
|----------------------------|--|
| Slice: | User selects either SIZE OF SLICES or NUMBER OF SLICES. |
| Size of Slices | Specifies the slice size in microns. The number of slices to be milled will be calculated by dividing the size of the defect (determined by Fiducial tool) by the size of the slices. |
| Limit max # of slices to | The maximum number of slices to be made in the Slice and View area. |
| Number of Slices | Specifies the number of slices to be milled. The height of each slice is determined by the software dividing the value specified for height (y) by the number of slices. Where is height from? A maximum of 100 individual patterns can be displayed. If the tool calls for more than 100 slices, an outline indicating the overall area to be sliced is displayed. |
| Depth | Specifies the pattern depth in microns. |
| Half Cut | Mills only half way through the defect selected (up to the center cross). |
| Material File | Displays a dropdown list for selecting a material file (.mtr). The list contains an entry for every material file available on the system. The default material file is si.mtr. |
| Max Process Time | The maximum time process may occur |
| Metal Deposition: | |
| Add Protective Coating: | If this option is selected, a protective layer will be centered about the Slice and View area. The scale will be set in the job builder configuration and based upon the size of the slice and view area. If protective coating is not selected, the fields associated with it should be inactive. |
| Material File | Displays a dropdown list for selecting a material file (.mtr). The list contains an entry for every material file available on the system. The default material file is either pt_high.mtr. |
| Pattern Width | Specifies the pattern width, as a percentage of the defect size. |
| Pattern Height | Specifies the pattern height, in microns. |
| Image: | |
| Scan Speed Matrix | Sets the frame time and resolution used for the electron beam images of the cross-section face. These values correspond generally to the faster continuous scan rates available in xP. Refer to the xP DualBeam Workstation User's Guide for information about the available resolutions. |
| Integrate | Number of frames to integrate for accumulative noise reduction. |
| Data Bar | Includes the databar configured in xP in the image. |
| ACB | Selects automatically adjusting contrast and brightness, using the stored values for comparison. |
| Track Image | Adjusts the electron beam shift to keep the face of the cross section centered in the field of view. |
| Auto Focus | Initiates automated focus before the system begins capturing electron beam images. |
| Field of View | Specifies the field of view used for electron beam images of the cross-section face, as a percentage of the cross-section. |
| Electron HV and Spotsizes: | kV specifies the electron beam accelerating voltage. Select from the range of voltages available for the currently selected imaging mode. SPOTSIZE specifies the actual focused area of the electron beam on the sample. |
| Mode | Select UHR or Search as the imaging mode. |
| Detector | Select the detector to be used for the electron beam images. Choices are determined by the currently selected imaging mode. |

Figure 17B

Auto Script Settings

Script File Path

Log File Path

Figure 18A

| Item | Description |
|------------------|---|
| Script File Path | Name and path of the AutoScript file. |
| Browse | Accesses the Open dialog box so you can navigate to a script file. |
| Edit File | Opens the selected script file in the Windows Notepad® text editor. |
| Log File Path | Name and path of the log file. |
| Browse | Accesses the Open dialog box so you can navigate to the log file. |

Figure 18B

System Settings

Get Current System Settings

Stage

☐ Absolute
☒ Relative

☐ X

☐ Y

☐ Z

☐ R

☐ T

Beam

☐ Primary Beam
☒ Electron
☐ Ion

☐ Magnification

☐ Scan Rotation

Electron Beam

☐ kV

☐ FWD

☐ Spot

☐ Mode
☐ UHR
☒ Search

Figure 19A


| Item | Description |
|-------------------------|--|
| GetCurrentSystemSetting | Gets the current system settings for all options |
| Stage: | |
| Absolute | Chooses coordinates measured from the center of the stage |
| Relative | Chooses coordinates measured from the current location on the stage |
| X, Y, Z, R, T | Sets the positions of the five independent axes |
| Beam: | |
| Primary Beam | Sets the ion beam or electron beam as the primary beam. The selected beam sets the magnification and other image data of the current image window. |
| Magnification | Sets magnification to the specified value. |
| Scan Rotation | Sets scan rotation to the specified value. |
| Electron Beam: | |
| kV | Sets the accelerating voltage for the electron beam. Choose a value from the adjacent dropdown list. |
| FWD | Sets the electron beam focus to the free working distance specified in the adjacent edit box. |
| Spot | Sets the aperture size for the electron beam. Choose a value from the adjacent dropdown list. |
| Mode | Selects the mode for the electron beam. |
| Ion Beam: | |
| Ion Aperture | Sets the ion beam current to the aperture (in pA) specified in the adjacent dropdown list. |

Figure 19B

| ADR Parameters | |
|---|------------|
| Die Offset (x-axis) | 5000 |
| <input type="checkbox"/> Center Defect | %FOV Text2 |
| <input type="checkbox"/> Probe Eucentric for Reference Image? | |
| DThresh | Display: |
| 12 | 3 |
| Noise Filter: | |
| Full | |

| | |
|--|---|
| <input type="checkbox"/> use system state | Electron HV and Spot Size |
| <input checked="" type="radio"/> E-Beam <input type="radio"/> I-Beam | 1kV 3 |
| Magnification | 3 |
| <input type="radio"/> FOV | |
| <input checked="" type="radio"/> Fixed 2500x | |
| Detector | Mode |
| <input checked="" type="radio"/> TLD-S | <input type="radio"/> UHR |
| <input type="radio"/> TLD-A | <input checked="" type="radio"/> Search |
| <input type="radio"/> TLD-C | |
| <input type="radio"/> TLD-D | Integrate |
| <input type="radio"/> CDM-E | 1 |
| <input type="radio"/> CDM-H | |
| Resolution | Med - 5.66 |
| <input checked="" type="checkbox"/> Save Data Bar On Image | |
| <input type="checkbox"/> ACB | |
| <input type="checkbox"/> AutoFocus | |
| <input type="checkbox"/> AutoStig | |

Figure 20A






Figure 21




Figure 22




Figure 23A






Figure 23B



**Figure 25**





Figure 26A

**Figure 26B**




Figure 27