

FIG. 1A




FIG. 1B




FIG. 2

FEI xP—Mock (Supervisor)

File Scan Detector DB Control E-Mag I-Mag E-Beam I-Beam Patterning Stage Tools Window Help

Build

Save

Save As

Open

Close

Job Information

Job File: TestJob
Defect File: FEI.rtf
Lot ID: 060601
WaferID: 23
OperatorID: W.Bee

Site Tools

Add tool to Process

Remove tool from Process

Available Tools:

Grab Image

Pattern

Beam Coincidence

Pause

Too Description:

Will make both beams point at the same spot needed for imaging while milling.

Site Process:

Grab Image

Pause

Beam

Det

Scan

FWD

Mag

Beam

Det

Scan

FWD

Mag

Number of Sites:

None

Status:

None

Cursor (Wafer)

CR +26 -012

XY 089.6437-68.0549

z006.0807

FIG. 3A

Item	Description
Job Builder:	
Build	Initiates building of new job
Save	Save the job information.
Save As	Functions conventionally
Open	Functions conventionally
Close	Functions conventionally
Job Information	Functions conventionally
Site Tools:	
Add Tool to Process	Inserts selected tool into process
Remove Tool from Process	removes selected tool from process
Available Tools	Displays tools available for processes
Tool Description	Brief description of tool
Site Process	Displays process (recipe) as it is being constructed by user

FIG. 3B

Available Tools: Grab Image Pattern Beam Coincidence Pause
Tool Description: Will make both beams point at the same spot needed for imaging while milling
Site Process: Grab Image Pause

FIG. 3C

Job Wafer Data Input		
Job Wafer Data Input		
Operator ID:	W. Bee	...
Defect File:	fei.rff	...
Lot ID:	060265	...
Wafer ID:	01	...
Job File:	TestJob.dar	...
Product:	Train Align	...
<input type="checkbox"/> Unload Wafer when Job Complete		
Run		Cancel

FIG. 3D

Review Session

Align To...	End Review
Filter...	
Move To...	Realign...

FIG. 3E

Edit Active Site Filter

Filter Name

Filter Criteria

Classification	<input checked="" type="checkbox"/>	1,2,3-4,7
Size x (μm)	<input checked="" type="checkbox"/>	2-12
Size y (μm)	<input checked="" type="checkbox"/>	1,2
Die Column:	<input type="checkbox"/>	
Die Row	<input type="checkbox"/>	
SLI	<input type="checkbox"/>	

Visited ☒ Yes ☐ No ☐

Modified ☒ Yes ☐ No ☐

Has Image ☐ Yes ☐ No ☐

ADE Channel ☐ Light ☐ Dark ☐

SP1 Channel ☒ Composite

Modified ☒ Bright Field

Modified ☒ Dark Wide

Modified ☒ Dark Narrow

New Open...

Save Save As...

Random Subset

☐ Enable Random Subset

50 Percent

Test Results

Apply Now

Total Sites	595
Filtered Out	0
Remaining	595

☐ Temporary Disable Filter

Class List... Undo Undo All Close

FIG. 3F

Interface Items	Description
Filter Name	Identifies the filter.
Filter Criteria	These check boxes and list boxes select the filter criteria
New	Creates a new filter file.
Open	Opens an existing filter.
Save	Saves the edited filter definition. It is available only if allowed by configuration.
Save As	Saves the edited filter definition to a new file name. It is available only if allowed by configuration.
Random Subset	Specifies the maximum number of random sites passing the filter.
Test Results	Tests and reports the effect of site filter changes.
Temporarily Disable Filter	Temporarily disables the active site filter.
Graph	Displays a histogram of the defect sites.
Class List	Opens the Edit Class List dialog box.
Undo	Undoes the last change. You cannot undo changes already saved to file.
Undo All+	Undoes all changes made since dialog box opened. You cannot undo changes already saved to file.
Close	Closes the dialog box. Applies the defined filter to the current review session but does not save the filter to file.

FIG. 3G

Criterion	Value Type	Description
Classification	Integer	Classification code assigned to the site
Size X (μm)	Real	X dimension of the site in microns
Size Y (μm)	Real	Y dimension of the site in microns
Die Column+n	Integer	Die column of the die containing the site
Die Row	Integer	Die row of the die containing the site
SLI	Integer	Scattered light intensity reported for the site
Visited	Yes/No	Site has or has not been visited during the review session
Modified	Yes/No	Site has or has not been classified or relocated during the review session
ADE Channel	Light/Dark	Site has or has not been visited during the review session
SP1 Channel	n/a	Site has selected attributes. This filter is active if the defect format is T7x00 and the defect file has more than one channel.
Has Image	Yes/No	Site has or does not have image data associated with it

FIG. 3H

Relational Operators	Meaning
=	Equal to
!=	Not equal to
<	Less than
<=	Less than or equal to
>	Greater than
>=	Greater than or equal to

FIG. 3I

9/68

Random Subset

☒ Enable Random Subset

50 Percent ▼

Percent

Maximum

FIG. 3J

Test Results

Apply Now

Total Sites 68
Filtered Out 0
Remaining 68

FIG. 3K

Defect File fei2.001
Wafer ID @05
Lot ID K54148350
Process ID 814FC
68 Total Sites, 68 Passing Filter

FIG. 3L

☒ Temporarily Disable Filter

FIG. 3M

Defect #	Size X	Size Y	Classification Recipe Name	Die Row

FIG. 3N




FIG. 30




FIG. 3P





Control	Descriptions	Behavior
	<p>Product/Step Tree: This is the interface through which specific Steps are created, edited, and deleted.</p>	<p>Sorting: Alphabetized by Product, then by Step.</p> <p>Node Behavior: Expandable and Collapsible through a standard interface. Persist Expansions for the life of the dialogue.</p> <p>Scroll Bars: Scrolling should be allowed.</p>
	<p>New Product Button: This is used to add a New Product to the Database.</p>	<p>Click: This should launch a "New Product Wizard" which is described below.</p>
	<p>New Step Button: This is used to add a New Step to whichever product is selected in the Product/Step Tree View (above).</p>	<p>Enable/Disable: Enable if a Product has been selected. Disabled otherwise.</p> <p>Click: This should launch the "New Step Wizard" which is described below.</p>
	<p>Delete Button: This is used to remove products or steps from the database</p>	<p>Click: This should launch a standard two-button dialogue with the message, "Permanently Delete [Product/Step] Information?". Then buttons are "Cancel" and "OK".</p>

FIG. 3Q




FIG. 3R




FIG. 3S







Control	Descriptions	Behavior
	<p>Site Sequence List Tree View: This displays a list of Site Sequences which can be expanded to show the names of the tools.</p>	<p>Scrolling: Should be scrollable.</p> <p>Node Behavior: Expanded nodes should stay expanded.</p> <p>Alphabetized.</p> <p>Click: This should highlight the site sequence.</p> <p>Default selection: The first site sequence in the list should be highlighted by default.</p> <p>Double-Click: This should expand the node to display the list of tools within the site sequence.</p> <p>Mouse Over: This should display the Site Sequence Name followed by the text description of the site sequence (if any).</p>
	<p>Edit Button: This loads the site sequence into the Recipe Builder page.</p>	<p>(Optionally) the page display should be switched to the Recipe Builder</p> <p>Click: Load the selected site sequence into the recipe builder page</p>
	<p>View Info Button: THIS BUTTON HAS BEEN REMOVED.</p>	<p>NOT APPLICABLE. (the tree view functionality eliminates the previously envisioned function of this button).</p>
	<p>Delete Button: This button removes the site sequence from the database.</p>	<p>Click: This removes the site sequence from the database as far as the user is concerned. The actual implementation should include an "Is Deleted" flag to indicate that the site sequence should not be displayed. This will prevent previously configured process from being invalidated.</p>
	<p>Site Filter Text Box: This shows a list of all Site Filters available for the selected Product/Step in the Product/Step Tree View control (above).</p>	<p>Alphabetize.</p> <p>Click: Highlight the site filter.</p> <p>Default Selection: The first of the list should be highlighted by default..</p>
	<p>Edit Button: This is used to edit the highlighted site filter.</p>	<p>Click: Launch the site filter dialog for the highlighted site filter.</p>

FIG. 3T




FIG. 3U

[illegible]

FIG. 3W





Control	Descriptions	Behavior
	Alignment Data Tree View. This is a tree view showing the Alignment data in the following order.	<p>Node coloring: The nodes should be colored red if they or a child is untrained.</p> <p>Data Structure: A preliminary data structure for this tree is shown and described in the following section.</p>
	Test Button. If appropriate, this should test the selected alignment on the wafer loaded into the system.	<p>Enable/Disable: This is dependent on the highlight node of the Alignment Data Tree View. For certain alignments test functionality will not be appropriate and should not, therefore, be applied.</p> <p>Click: Run the alignment for the highlighted node and all child nodes in the Alignment Data Tree View.</p>
	Train Button. If appropriate, this should initiate the portion of the Alignment Training Wizard for the selected node.	<p>Enable/Disable: For some nodes this control may not make sense or may require functionality not provided by the software. In these situations the control should be either disabled or handled through a clear, concise error message. For example, training the zero degree alignments for a wafer loaded at 52 degrees might prompt the user to tilt to zero degrees and try the alignment again.</p> <p>Click: Run the portion(s) of the alignment training wizard for the highlighted node and child nodes. Note that there may be unanticipated exceptions that need to be dealt with (such as no wafer is loaded) that will require increased robustness in handling of errors and exceptions. These will be ferreted out at a later time.</p>
	Delete Button: This permanently deletes alignment data from the database.	Click: This should launch a standard two button dialogue with the message "This will

FIG. 3V

Control	Descriptions	Behavior
HIDE RECIPE EXPLORER		
Recipes	<p>Recipe Tab. This should have the following fields.</p> <ul style="list-style-type: none"> ○ Product ○ Step ○ Recipe Name ○ Creation Date 	
Site Filters	<p>Site Filter Tab. This should have the fields listed below. As an added feature, there could be a "view filter button" to allow a quick look at the data through a new window</p> <ul style="list-style-type: none"> ○ Product ○ Step ○ Recipe Name ○ Creation Date 	
Site Maps	<p>Site Map Tab. This should have the fields listed below. As an added feature, there could be a "view filter button" to allow a quick look at the data in a new window (similar to above).</p> <ul style="list-style-type: none"> ○ Product ○ Step ○ Recipe Name ○ Creation Date 	
Alignment Data	<p>Site Map Tab. This is a complex control, but the should have the fields listed below. Alignment Node should be path which indicates where the alignment data exists on a tree structure identical to that described above.</p> <ul style="list-style-type: none"> ○ Product 	

FIG. 3X

- ◇ Alignment Name #1
 - Wafer Alignment
 - Product Offset
 - Zero Degrees
 - Alignment Dies
 - Top-Down Electron Beam Image
 - Ion Beam Image
 - Fifty-Two Degrees
 - Alignment Dies
 - Ion Beam Image
 - Electron Beam Image
 - System Calibrations
 - Height Probe Offset
 - Zero Degrees
 - Fifty-Two Degrees
- ◇ Alignment Name #2

FIG. 3Y




FIG. 4A

Item	Description
Run	Loads the wafer and runs the selected job.
Pause	Pause job execution
Abort	Terminate job execution
Description	Comment text describing job if included in job
Site Process	Displays job process tools

FIG. 4B




FIG. 4C

Job Wafer Data Input

Job Wafer Data Input

Operator ID: W. Bee ...

Defect File: fei.rff ...

Lot ID: 060265 ...

Wafer ID: 01 ...

Job File: TestJob.dar ...

Product: Train Align ...

☐ Unload Wafer when Job Complete

Run Cancel

FIG. 4D

Interface Items	Description
Operator ID	Required field where the user enters name.
Detect File	Defect file for the job. User opens an existing defect file. Clicking the select button opens the Select Defect dialog box.
Lot ID	Maximum of 15 characters. Value is read in from defect file or job file, selected from dialog box, or entered by the operator.
Wafer ID	Maximum of 5 characters. Value is read in from defect file or job file, selected from dialog box, or entered by the operator.
Job File	Selects a recipe or job file. The recipe contains no wafer information, the job file contains wafer information. They have different extensions, .daj and .dar.
Product	Identifies the alignment wizard for the wafer. If TRAIN ALIGN is selected, when the user clicks RUN, the Alignment Training wizard starts.
Cass A/B	Shows the slots that are occupied.
Inventory	Inventories the cassettes.
FlexiLock	Shows if wafer is in the cassette.
Unload wafer when job complete	Provides automated wafer unloading when a job is complete.
RUN	Dialog box closes and the Information dialog box displays. When user clicks OK in information dialog box the sequencer runs the job. This button is not active until information for at least one wafer is entered.
Cancel	Dialog box closes without saving the values. In job builder, the dialog box closes and the Add Tool interface displays. In sequencer, a warning box displays so that the user does not unintentional lose information. Then, the Sequencer page becomes active again.
Select button	Open dialog where predefined files, wafer, etc., can be selected.

FIG. 4E

Job Wafer Data Input			Class A		Class B		Inventory
Operator ID:	<input type="text" value="W. Bee"/>	<input data-bbox="634 556 669 583" type="button" value="..."/>	<input type="text" value="1"/>	<input type="text" value="2"/>	<input type="text" value="1"/>	<input type="text" value="2"/>	<input type="button" value="Inventory"/>
Defect File:	<input type="text" value="fei.rff"/>	<input data-bbox="634 627 669 657" type="button" value="..."/>	<input type="text" value="3"/>	<input type="text" value="4"/>	<input type="text" value="3"/>	<input type="text" value="4"/>	
Lot ID:	<input type="text" value="060265"/>	<input data-bbox="634 693 669 720" type="button" value="..."/>	<input type="text" value="5"/>	<input type="text" value="6"/>	<input type="text" value="5"/>	<input type="text" value="6"/>	
Wafer ID:	<input type="text" value="01"/>	<input data-bbox="634 756 669 785" type="button" value="..."/>	<input type="text" value="7"/>	<input type="text" value="8"/>	<input type="text" value="7"/>	<input type="text" value="8"/>	
Job File:	<input type="text" value="TestJob.dar"/>	<input data-bbox="634 821 669 848" type="button" value="..."/>	<input type="text" value="9"/>	<input type="text" value="10"/>	<input type="text" value="9"/>	<input type="text" value="10"/>	
Product:	<input type="text" value="Train Align"/>	<input data-bbox="634 884 669 913" type="button" value="..."/>	<input type="text" value="11"/>	<input type="text" value="12"/>	<input type="text" value="11"/>	<input type="text" value="12"/>	
<div><input data-bbox="315 940 485 984" type="button" value="Run"/><input data-bbox="566 940 737 984" type="button" value="Cancel"/></div>			<input type="text" value="13"/>	<input type="text" value="14"/>	<input type="text" value="13"/>	<input type="text" value="14"/>	
			<input type="text" value="15"/>	<input type="text" value="16"/>	<input type="text" value="15"/>	<input type="text" value="16"/>	
			<input type="text" value="17"/>	<input type="text" value="18"/>	<input type="text" value="17"/>	<input type="text" value="18"/>	
			<input type="text" value="19"/>	<input type="text" value="20"/>	<input type="text" value="19"/>	<input type="text" value="20"/>	
			<input type="text" value="21"/>	<input type="text" value="22"/>	<input type="text" value="21"/>	<input type="text" value="22"/>	
			<input type="text" value="23"/>	<input type="text" value="24"/>	<input type="text" value="23"/>	<input type="text" value="24"/>	
			<input type="text" value="25"/>	<input type="text" value="25"/>	<input type="text" value="25"/>	<input type="text" value="25"/>	

FIG. 4F

Job Wafer Data Input			
Job Wafer Data Input			
Operator ID:	<input type="text" value="W. Bee"/>	<input data-bbox="630 562 670 604" type="button" value="..."/>	
Defect File:	<input type="text" value="fei.rff"/>	<input data-bbox="630 630 670 672" type="button" value="..."/>	
Lot ID:	<input type="text" value="060265"/>	<input data-bbox="630 697 670 739" type="button" value="..."/>	
Wafer ID:	<input type="text" value="01"/>	<input data-bbox="630 764 670 806" type="button" value="..."/>	
Job File:	<input type="text" value="TestJob.dar"/>	<input data-bbox="630 831 670 873" type="button" value="..."/>	
Product:	<input type="text" value="Train Align"/>	<input data-bbox="630 898 670 940" type="button" value="..."/>	
<input data-bbox="310 947 488 989" type="button" value="Run"/>		<input data-bbox="570 947 748 989" type="button" value="Cancel"/>	
		Class A	Class B
		<input data-bbox="829 552 919 583" type="checkbox"/>	<input data-bbox="1024 552 1114 583" type="checkbox"/>
		<input data-bbox="829 583 919 615" type="checkbox"/>	<input data-bbox="1024 583 1114 615" type="checkbox"/>
		<input data-bbox="829 615 919 646" type="checkbox"/>	<input data-bbox="1024 615 1114 646" type="checkbox"/>
		<input data-bbox="829 646 919 678" type="checkbox"/>	<input data-bbox="1024 646 1114 678" type="checkbox"/>
		<input data-bbox="829 678 919 709" type="checkbox"/>	<input data-bbox="1024 678 1114 709" type="checkbox"/>
		<input data-bbox="829 709 919 741" type="checkbox"/>	<input data-bbox="1024 709 1114 741" type="checkbox"/>
		<input data-bbox="829 741 919 772" type="checkbox"/>	<input data-bbox="1024 741 1114 772" type="checkbox"/>
		<input data-bbox="829 772 919 804" type="checkbox"/>	<input data-bbox="1024 772 1114 804" type="checkbox"/>
		<input data-bbox="829 804 919 835" type="checkbox"/>	<input data-bbox="1024 804 1114 835" type="checkbox"/>
		<input data-bbox="829 835 919 867" type="checkbox"/>	<input data-bbox="1024 835 1114 867" type="checkbox"/>
		<input data-bbox="829 867 919 898" type="checkbox"/>	<input data-bbox="1024 867 1114 898" type="checkbox"/>
		<input data-bbox="829 898 919 930" type="checkbox"/>	<input data-bbox="1024 898 1114 930" type="checkbox"/>
		<input data-bbox="829 930 919 961" type="checkbox"/>	<input data-bbox="1024 930 1114 961" type="checkbox"/>
		<input data-bbox="829 961 919 993" type="checkbox"/>	<input data-bbox="1024 961 1114 993" type="checkbox"/>
		<input data-bbox="829 993 919 1024" type="checkbox"/>	<input data-bbox="1024 993 1114 1024" type="checkbox"/>
		<input data-bbox="829 1024 919 1056" type="checkbox"/>	<input data-bbox="1024 1024 1114 1056" type="checkbox"/>
		<input data-bbox="829 1056 919 1087" type="checkbox"/>	<input data-bbox="1024 1056 1114 1087" type="checkbox"/>
		<input data-bbox="829 1087 919 1119" type="checkbox"/>	<input data-bbox="1024 1087 1114 1119" type="checkbox"/>
		<input data-bbox="829 1119 919 1150" type="checkbox"/>	<input data-bbox="1024 1119 1114 1150" type="checkbox"/>
		<input data-bbox="829 1150 919 1182" type="checkbox"/>	<input data-bbox="1024 1150 1114 1182" type="checkbox"/>
		<input data-bbox="829 1182 919 1213" type="checkbox"/>	<input data-bbox="1024 1182 1114 1213" type="checkbox"/>
		<input data-bbox="829 1213 919 1245" type="checkbox"/>	<input data-bbox="1024 1213 1114 1245" type="checkbox"/>
		<input data-bbox="829 1245 919 1276" type="checkbox"/>	<input data-bbox="1024 1245 1114 1276" type="checkbox"/>
		<input data-bbox="829 1276 919 1308" type="checkbox"/>	<input data-bbox="1024 1276 1114 1308" type="checkbox"/>
		<input data-bbox="829 1308 919 1339" type="checkbox"/>	<input data-bbox="1024 1308 1114 1339" type="checkbox"/>
		<input data-bbox="829 1339 919 1371" type="checkbox"/>	<input data-bbox="1024 1339 1114 1371" type="checkbox"/>
		<input data-bbox="829 1371 919 1402" type="checkbox"/>	<input data-bbox="1024 1371 1114 1402" type="checkbox"/>
		<input data-bbox="829 1402 919 1434" type="checkbox"/>	<input data-bbox="1024 1402 1114 1434" type="checkbox"/>
		<input data-bbox="829 1434 919 1465" type="checkbox"/>	<input data-bbox="1024 1434 1114 1465" type="checkbox"/>
		<input data-bbox="829 1465 919 1497" type="checkbox"/>	<input data-bbox="1024 1465 1114 1497" type="checkbox"/>
		<input data-bbox="829 1497 919 1528" type="checkbox"/>	<input data-bbox="1024 1497 1114 1528" type="checkbox"/>
		<input data-bbox="829 1528 919 1560" type="checkbox"/>	<input data-bbox="1024 1528 1114 1560" type="checkbox"/>
		<input data-bbox="829 1560 919 1591" type="checkbox"/>	<input data-bbox="1024 1560 1114 1591" type="checkbox"/>
		<input data-bbox="829 1591 919 1623" type="checkbox"/>	<input data-bbox="1024 1591 1114 1623" type="checkbox"/>
		<input data-bbox="829 1623 919 1654" type="checkbox"/>	<input data-bbox="1024 1623 1114 1654" type="checkbox"/>
		<input data-bbox="829 1654 919 1686" type="checkbox"/>	<input data-bbox="1024 1654 1114 1686" type="checkbox"/>
		<input data-bbox="829 1686 919 1717" type="checkbox"/>	<input data-bbox="1024 1686 1114 1717" type="checkbox"/>
		<input data-bbox="829 1717 919 1749" type="checkbox"/>	<input data-bbox="1024 1717 1114 1749" type="checkbox"/>
		<input data-bbox="829 1749 919 1780" type="checkbox"/>	<input data-bbox="1024 1749 1114 1780" type="checkbox"/>
		<input data-bbox="829 1780 919 1812" type="checkbox"/>	<input data-bbox="1024 1780 1114 1812" type="checkbox"/>
		<input data-bbox="829 1812 919 1843" type="checkbox"/>	<input data-bbox="1024 1812 1114 1843" type="checkbox"/>
		<input data-bbox="829 1843 919 1875" type="checkbox"/>	<input data-bbox="1024 1843 1114 1875" type="checkbox"/>
		<input data-bbox="829 1875 919 1906" type="checkbox"/>	<input data-bbox="1024 1875 1114 1906" type="checkbox"/>
		<input data-bbox="829 1906 919 1938" type="checkbox"/>	<input data-bbox="1024 1906 1114 1938" type="checkbox"/>
		<input data-bbox="829 1938 919 1969" type="checkbox"/>	<input data-bbox="1024 1938 1114 1969" type="checkbox"/>
		<input data-bbox="829 1969 919 2001" type="checkbox"/>	<input data-bbox="1024 1969 1114 2001" type="checkbox"/>
		<input data-bbox="829 2001 919 2032" type="checkbox"/>	<input data-bbox="1024 2001 1114 2032" type="checkbox"/>
		<input data-bbox="829 2032 919 2064" type="checkbox"/>	<input data-bbox="1024 2032 1114 2064" type="checkbox"/>
		<input data-bbox="829 2064 919 2095" type="checkbox"/>	<input data-bbox="1024 2064 1114 2095" type="checkbox"/>
		<input data-bbox="829 2095 919 2100" type="checkbox"/>	<input data-bbox="1024 2095 1114 2100" type="checkbox"/>
		<input data-bbox="829 2127 919 2100" type="checkbox"/>	<input data-bbox="1024 2127 1114 2100" type="checkbox"/>
		<input data-bbox="829 2158 919 2100" type="checkbox"/>	<input data-bbox="1024 2158 1114 2100" type="checkbox"/>
		<input data-bbox="829 2190 919 2100" type="checkbox"/>	<input data-bbox="1024 2190 1114 2100" type="checkbox"/>
		<input data-bbox="829 2221 919 2100" type="checkbox"/>	<input data-bbox="1024 2221 1114 2100" type="checkbox"/>
		<input data-bbox="829 2253 919 2100" type="checkbox"/>	<input data-bbox="1024 2253 1114 2100" type="checkbox"/>
		<input data-bbox="829 2284 919 2100" type="checkbox"/>	<input data-bbox="1024 2284 1114 2100" type="checkbox"/>
		<input data-bbox="829 2316 919 2100" type="checkbox"/>	<input data-bbox="1024 2316 1114 2100" type="checkbox"/>
		<input data-bbox="829 2347 919 2100" type="checkbox"/>	<input data-bbox="1024 2347 1114 2100" type="checkbox"/>
		<input data-bbox="829 2379 919 2100" type="checkbox"/>	<input data-bbox="1024 2379 1114 2100" type="checkbox"/>
		<input data-bbox="829 2410 919 2100" type="checkbox"/>	<input data-bbox="1024 2410 1114 2100" type="checkbox"/>
		<input data-bbox="829 2442 919 2100" type="checkbox"/>	<input data-bbox="1024 2442 1114 2100" type="checkbox"/>
		<input data-bbox="829 2473 919 2100" type="checkbox"/>	<input data-bbox="1024 2473 1114 2100" type="checkbox"/>
		<input data-bbox="829 2505 919 2100" type="checkbox"/>	<input data-bbox="1024 2505 1114 2100" type="checkbox"/>
		<input data-bbox="829 2536 919 2100" type="checkbox"/>	<input data-bbox="1024 2536 1114 2100" type="checkbox"/>
		<input data-bbox="829 2568 919 2100" type="checkbox"/>	<input data-bbox="1024 2568 1114 2100" type="checkbox"/>
		<input data-bbox="829 2599 919 2100" type="checkbox"/>	<input data-bbox="1024 2599 1114 2100" type="checkbox"/>
		<input data-bbox="829 2631 919 2100" type="checkbox"/>	<input data-bbox="1024 2631 1114 2100" type="checkbox"/>
		<input data-bbox="829 2662 919 2100" type="checkbox"/>	<input data-bbox="1024 2662 1114 2100" type="checkbox"/>
		<input data-bbox="829 2694 919 2100" type="checkbox"/>	<input data-bbox="1024 2694 1114 2100" type="checkbox"/>
		<input data-bbox="829 2725 919 2100" type="checkbox"/>	<input data-bbox="1024 2725 1114 2100" type="checkbox"/>
		<input data-bbox="829 2757 919 2100" type="checkbox"/>	<input data-bbox="1024 2757 1114 2100" type="checkbox"/>
		<input data-bbox="829 2788 919 2100" type="checkbox"/>	<input data-bbox="1024 2788 1114 2100" type="checkbox"/>
		<input data-bbox="829 2820 919 2100" type="checkbox"/>	<input data-bbox="1024 2820 1114 2100" type="checkbox"/>
		<input data-bbox="829 2851 919 2100" type="checkbox"/>	<input data-bbox="1024 2851 1114 2100" type="checkbox"/>
		<input data-bbox="829 2883 919 2100" type="checkbox"/>	<input data-bbox="1024 2883 1114 2100" type="checkbox"/>
		<input data-bbox="829 2914 919 2100" type="checkbox"/>	<input data-bbox="1024 2914 1114 2100" type="checkbox"/>
		<input data-bbox="829 2946 919 2100" type="checkbox"/>	<input data-bbox="1024 2946 1114 2100" type="checkbox"/>
		<input data-bbox="829 2977 919 2100" type="checkbox"/>	<input data-bbox="1024 2977 1114 2100" type="checkbox"/>
		<input data-bbox="829 3009 919 2100" type="checkbox"/>	<input data-bbox="1024 3009 1114 2100" type="checkbox"/>
		<input data-bbox="829 3040 919 2100" type="checkbox"/>	<input data-bbox="1024 3040 1114 2100" type="checkbox"/>
		<input data-bbox="829 3072 919 2100" type="checkbox"/>	<input data-bbox="1024 3072 1114 2100" type="checkbox"/>
		<input data-bbox="829 3103 919 2100" type="checkbox"/>	<input data-bbox="1024 3103 1114 2100" type="checkbox"/>
		<input data-bbox="829 3135 919 2100" type="checkbox"/>	<input data-bbox="1024 3135 1114 2100" type="checkbox"/>
		<input data-bbox="829 3166 919 2100" type="checkbox"/>	<input data-bbox="1024 3166 1114 2100" type="checkbox"/>
		<input data-bbox="829 3198 919 2100" type="checkbox"/>	<input data-bbox="1024 3198 1114 2100" type="checkbox"/>
		<input data-bbox="829 3229 919 2100" type="checkbox"/>	<input data-bbox="1024 3229 1114 2100" type="checkbox"/>
		<input data-bbox="829 3261 919 2100" type="checkbox"/>	<input data-bbox="1024 3261 1114 2100" type="checkbox"/>
		<input data-bbox="829 3292 919 2100" type="checkbox"/>	<input data-bbox="1024 3292 1114 2100" type="checkbox"/>
		<input data-bbox="829 3324 919 2100" type="checkbox"/>	<input data-bbox="1024 3324 1114 2100" type="checkbox"/>
		<input data-bbox="829 3355 919 2100" type="checkbox"/>	<input data-bbox="1024 3355 1114 2100" type="checkbox"/>
		<input data-bbox="829 3387 919 2100" type="checkbox"/>	<input data-bbox="1024 3387 1114 2100" type="checkbox"/>
		<input data-bbox="829 3418 919 2100" type="checkbox"/>	<input data-bbox="1024 3418 1114 2100" type="checkbox"/>
		<input data-bbox="829 3450 919 2100" type="checkbox"/>	<input data-bbox="1024 3450 1114 2100" type="checkbox"/>
		<input data-bbox="829 3481 919 2100" type="checkbox"/>	<input data-bbox="1024 3481 1114 2100" type="checkbox"/>
		<input data-bbox="829 3513 919 2100" type="checkbox"/>	<input data-bbox="1024 3513 1114 2100" type="checkbox"/>
		<input data-bbox="829 3544 919 2100" type="checkbox"/>	<input data-bbox="1024 3544 1114 2100" type="checkbox"/>
		<input data-bbox="829 3576 919 2100" type="checkbox"/>	<input data-bbox="1024 3576 1114 2100" type="checkbox"/>
		<input data-bbox="829 3607 919 2100" type="checkbox"/>	<input data-bbox="1024 3607 1114 2100" type="checkbox"/>
		<input data-bbox="829 3639 919 2100" type="checkbox"/>	<input data-bbox="1024 3639 1114 2100" type="checkbox"/>
		<input data-bbox="829 3670 919 2100" type="checkbox"/>	<input data-bbox="1024 3670 1114 2100" type="checkbox"/>
		<input data-bbox="829 3702 919 2100" type="checkbox"/>	<input data-bbox="1024 3702 1114 2100" type="checkbox"/>
		<input data-bbox="829 3733 919 2100" type="checkbox"/>	<input data-bbox="1024 3733 1114 2100" type="checkbox"/>
		<input data-bbox="829 3765 919 2100" type="checkbox"/>	<input data-bbox="1024 3765 1114 2100" type="checkbox"/>
		<input data-bbox="829 3796 919 2100" type="checkbox"/>	<input data-bbox="1024 3796 1114 2100" type="checkbox"/>
		<input data-bbox="829 3828 919 2100" type="checkbox"/>	<input data-bbox="1024 3828 1114 2100" type="checkbox"/>
		<input data-bbox="829 3859 919 2100" type="checkbox"/>	<input data-bbox="1024 3859 1114 2100" type="checkbox"/>
		<input data-bbox="829 3891 919 2100" type="checkbox"/>	<input data-bbox="1024 3891 1114 2100" type="checkbox"/>
		<input data-bbox="829 3922 919 2100" type="checkbox"/>	<input data-bbox="1024 3922 1114 2100" type="checkbox"/>
		<input data-bbox="829 3954 919 2100" type="checkbox"/>	<input data-bbox="1024 3954 1114 2100" type="checkbox"/>
		<input data-bbox="829 3985 919 2100" type="checkbox"/>	<input data-bbox="1024 3985 1114 2100" type="checkbox"/>
		<input data-bbox="829 4017 919 2100" type="checkbox"/>	<input data-bbox="1024 4017 1114 2100" type="checkbox"/>
		<input data-bbox="829 4048 919 2100" type="checkbox"/>	<input data-bbox="1024 4048 1114 2100" type="checkbox"/>
		<input data-bbox="829 4080 919 2100" type="checkbox"/>	<input data-bbox="1024 4080 1114 2100" type="checkbox"/>
		<input data-bbox="829 4111 919 2100" type="checkbox"/>	<input data-bbox="1024 4111 1114 2100" type="checkbox"/>
		<input data-bbox="829 4143 919 2100" type="checkbox"/>	<input data-bbox="1024 4143 1114 2100" type="checkbox"/>
		<input data-bbox="829 4174 919 2100" type="checkbox"/>	<input data-bbox="1024 4174 1114 2100" type="checkbox"/>
		<input data-bbox="829 4206 919 2100" type="checkbox"/>	<input data-bbox="1024 4206 1114 2100" type="checkbox"/>
		<input data-bbox="829 4237 919 2100" type="checkbox"/>	<input data-bbox="1024 4237 1114 2100" type="checkbox"/>
		<input data-bbox="829 4269 919 2100" type="checkbox"/>	<input data-bbox="1024 4269 1114 2100" type="checkbox"/>
		<input data-bbox="829 4300 919 2100" type="checkbox"/>	<input data-bbox="1024 4300 1114 2100" type="checkbox"/>
		<input data-bbox="829 4332 919 2100" type="checkbox"/>	<input data-bbox="1024 4332 1114 2100" type="checkbox"/>
		<input data-bbox="829 4363 919 2100" type="checkbox"/>	<input data-bbox="1024 4363 1114 2100" type="checkbox"/>
		<input data-bbox="829 4395 919 2100" type="checkbox"/>	<input data-bbox="1024 4395 1114 2100" type="checkbox"/>
		<input data-bbox="829 4426 919 2100" type="checkbox"/>	<input data-bbox="1024 4426 1114 2100" type="checkbox"/>
		<input data-bbox="829 4458 919 2100" type="checkbox"/>	<input data-bbox="1024 4458 1114 2100" type="checkbox"/>
		<input data-bbox="829 4489 919 2100" type="checkbox"/>	<input data-bbox="1024 4489 1114 2100" type="checkbox"/>
		<input data-bbox="829 4521 919 2100" type="checkbox"/>	<input data-bbox="1024 4521 1114 2100" type="checkbox"/>
		<input data-bbox="829 4552 919 2100" type="checkbox"/>	<input data-bbox="1024 4552 1114 2100" type="checkbox"/>
		<input data-bbox="829 4584 919 2100" type="checkbox"/>	<input data-bbox="1024 4584 1114 2100" type="checkbox"/>
		<input data-bbox="829 4615 919 2100" type="checkbox"/>	<input data-bbox="1024 4615 1114 2100" type="checkbox"/>
		<input data-bbox="829 4647 919 2100" type="checkbox"/>	<input data-bbox="1024 4647 1114 2100" type="checkbox"/>
		<input data-bbox="829 4678 919 2100" type="checkbox"/>	<input data-bbox="1024 4678 1114 2100" type="checkbox"/>
		<input data-bbox="829 4710 919 2100" type="checkbox"/>	<input data-bbox="1024 4710 1114 2100" type="checkbox"/>
		<input data-bbox="829 4741 919 2100" type="checkbox"/>	<input data-bbox="1024 4741 1114 2100" type="checkbox"/>
		<input data-bbox="829 4773 919 2100" type="checkbox"/>	<input data-bbox="1024 4773 1114 2100" type="checkbox"/>
		<input data-bbox="829 4804 919 2100" type="checkbox"/>	<input data-bbox="1024 4804 1114 2100" type="checkbox"/>
		<input data-bbox="829 4836 919 2100" type="checkbox"/>	<input data-bbox="1024 4836 1114 2100" type="checkbox"/>
		<input data-bbox="829 4867 919 2100" type="checkbox"/>	<input data-bbox="1024 4867 1114 2100" type="checkbox"/>
		<input data-bbox="829 4899 919 2100" type="checkbox"/>	<input data-bbox="1024 4899 1114 2100" type="checkbox"/>
		<input data-bbox="829 4930 919 2100" type="checkbox"/>	<input data-bbox="1024 4930 1114 2100" type="checkbox"/>
		<input data-bbox="829 4962 919 2100" type="checkbox"/>	<input data-bbox="1024 4962 1114 2100" type="checkbox"/>
		<input data-bbox="829 4993 919 2100" type="checkbox"/>	<input data-bbox="1024 4993 1114 2100" type="checkbox"/>
		<input data-bbox="829 5025 919 2100" type="checkbox"/>	<input data-bbox="1024 5025 1114 2100" type="checkbox"/>
		<input data-bbox="829 5056 919 2100" type="checkbox"/>	<input data-bbox="1024 5056 1114 2100" type="checkbox"/>
		<input data-bbox="829 5088 919 2100" type="checkbox"/>	<input data-bbox="1024 5088 1114 2100" type="checkbox"/>
		<input data-bbox="829 5119 919 2100" type="checkbox"/>	<input data-bbox="1024 5119 1114 2100" type="checkbox"/>
		<input data-bbox="829 5151 919 2100" type="checkbox"/>	<input data-bbox="1024 5151 1114 2100" type="checkbox"/>
		<input data-bbox="829 5182 919 2100" type="checkbox"/>	<input data-bbox="1024 5182 1114 2100" type="checkbox"/>
		<input data-bbox="829 5214 919 2100" type="checkbox"/>	<input data-bbox="1024 5214 1114 2100" type="checkbox"/>
		<input data-bbox="829 5245 919 2100" type="checkbox"/>	<input data-bbox="1024 5245 1114 2100" type="checkbox"/>
		<input data-bbox="829 5277 919 2100" type="checkbox"/>	<input data-bbox="1024 5277 1114 2100" type="checkbox"/>
		<input data-bbox="829 5308 919 2100" type="checkbox"/>	<input data-bbox="1024 5308 1114 2100" type="checkbox"/>
		<input data-bbox="829 5340 919 2100" type="checkbox"/>	<input data-bbox="1024 5340 1114 2100" type="checkbox"/>
		<input data-bbox="829 5371 919 2100" type="checkbox"/>	<input data-bbox="1024 5371 1114 2100" type="checkbox"/>
		<input data-bbox="829 5403 919 2100" type="checkbox"/>	<input data-bbox="1024 5403 1114 2100" type="checkbox"/>
		<input data-bbox="829 5434 919 2100" type="checkbox"/>	<input data-bbox="1024 5434 1114 2100" type="checkbox"/>
		<input data-bbox="829 5466 919 2100" type="checkbox"/>	<input data-bbox="1024 5466 1114 2100" type="checkbox"/>
		<input data-bbox="829 5497 919 2100" type="checkbox"/>	<input data-bbox="1024 5497 1114 2100" type="checkbox"/>
		<input data-bbox="829 5529 919 2100" type="checkbox"/>	<input data-bbox="1024 5529 1114 2100" type="checkbox"/>
		<input data-bbox="829 5560 919 2100" type="checkbox"/>	<input data-bbox="1024 5560 1114 2100" type="checkbox"/>
		<input data-bbox="829 5592 919 2100" type="checkbox"/>	<input data-bbox="1024 5592 1114 2100" type="checkbox"/>
		<input data-bbox="829 5623 919 2100" type="checkbox"/>	<input data-bbox="1024 5623 1114 2100" type="checkbox"/>
		<input data-bbox="829 5655 919 2100" type="checkbox"/>	<input data-bbox="1024 5655 1114 2100" type="checkbox"/>
		<input data-bbox="829 5686 919 2100" type="checkbox"/>	<input data-bbox="1024 5686 1114 2100" type="checkbox"/>




FIG. 4H




FIG. 4I

Defect File Contents		
Wafer ID	Inspection	Site Count

FIG. 4J

Column Header	Description
Wafer ID	The wafer ID as listed in the defect file.
Inspection	The date and time site list was created during inspection.
Wafer ID	The wafer ID as listed in the defect file.

FIG. 4K




FIG. 4L




FIG. 4M




FIG. 4N




FIG. 5

FEI Defect Explore

Search Criteria: _____

Select

Lot ID

Wafer ID

Job Start Date Job End Date

Quick Search

Job Details

<input checked="" type="checkbox"/> Job name		
<input checked="" type="checkbox"/> Job name		
<input checked="" type="checkbox"/> Job name		
<input checked="" type="checkbox"/> Job name		
<input checked="" type="checkbox"/> Job name		
<input checked="" type="checkbox"/> Job name		
<input checked="" type="checkbox"/> Job name		

FIG. 6A

FEI Defect Explorer

View Details of Jobs
Selected For Delete

View Details
Selected For
Export

View Site Details
Tagged For Revisit

View Details of
Images Selected
For Delete

Details

Delete Job

Eport

Tag for ReVisit

Delete Images

<Back

Sign Out

FIG. 6C




FIG. 6C






FIG. 7B

Realign		
Beam:	Type:	Assist Timeout:
<input type="text" value="Ion"/>	<input type="text" value="Beam Shift"/>	<input type="text" value="0"/>
<input type="checkbox"/> Display Match Dialog		<input type="checkbox"/> Suppress Errors
Offsets		
<input type="checkbox"/> Field Of View	X:	Y:
	<input type="text" value="0.000000"/>	<input type="text" value="0.000000"/>
Logging		
<input type="checkbox"/> Enable Logging	Log File:	
	<input type="text"/> ...	
<input type="button" value="Apply"/> <input type="button" value="Cancel"/>		

FIG. 8A

Item	Description
Realign	
Beam	Specifies the beam to be used in the alignment.
Type	Specifies measurement or the type of alignment. BEAM SHIFT specifies an alignment using beam shift MEASURE instructs the system to measure the X, Y distance between the center of the images and the center of the fiducial mark, in pixels and microns. The result is written to the user-specified log file. STAGE MOVE specifies an alignment using a stage move.
Assist Timeout	Number of seconds a dialog box remains on screen, prompting for user intervention. If this value is 0, no dialog box appears.
Display Match Dialog	Displays the Image Match dialog box (see Image Match).
Suppress Errors	When this option is selected, the system ignores image recognition errors. If ENABLE LOGGING is selected, image recognition errors are written to the user-specified log file.
Offsets:	
Field of View	Specifies a proportional shift of the field of view. When this option is selected, the system shifts the field of view by the proportion of the field of view specified in X and Y. When this option is not selected, the system shifts the field of view by the distance in microns specified in X and Y.
X,Y	Specify the distance by which the system shifts the field of view during alignment. When FIELD OF VIEW is selected, the values specified in X and Y denote a portion of the field of view-e.g., a value of 0.1 equals 10% of the field of view. In one embodiment, acceptable values are 0-1. When FIELD OF VIEW is not selected, the system shifts the field of view by the distance in microns specified in X and Y.
Logging:	
Enable Logging	When this option is selected and a log file is specified, the system logs the following information: Name and path of the image file used for realignment X location of the fiducial in pixels and microns Y location of the fiducial in pixels and microns When MEASURE is selected for TYPE, the X, Y distance between the center of the image and the center of the fiducial mark, in pixels and microns. If the fiducial is not found, the system writes "Fail" to the log file.
Log File	Name and path of the specified log file. Use the adjacent Browse button to navigate to the desired directory.

FIG. 8B

*FIG. 8C**FIG. 8D*

Cross Section Settings

Deposition	Bulk Mill	Cross Section
Material File <div style="border: 1px solid black; padding: 2px;">pt_high.mtr</div>	Material File <div style="border: 1px solid black; padding: 2px;">si.mtr</div>	Material File <div style="border: 1px solid black; padding: 2px;">si.mtr</div>
Width <div style="border: 1px solid black; padding: 2px;">10.00</div> %	Width <div style="border: 1px solid black; padding: 2px;">10.00</div> %	Width <div style="border: 1px solid black; padding: 2px;">10.00</div> %
Height <div style="border: 1px solid black; padding: 2px;">10.00</div> %	# of Cuts <div style="border: 1px solid black; padding: 2px;">10.00</div>	Height <div style="border: 1px solid black; padding: 2px;">10.00</div> %
Depth <div style="border: 1px solid black; padding: 2px;">0.50</div> μm	Maximum Total Time (Bulk Mill & Cross Section) <div style="border: 1px solid black; padding: 2px;">20.00</div> Seconds	

Y Offset

 Current Offset: 0.00 μm

Apply

Cancel

FIG. 9A

Item	Description
Description	
Material File	Displays a dropdown menu for selecting a material file (.mtr). The list contains an entry for every material file available on the system.
Width	Width of the specified cross section (X), as a percentage of the field of view.
Height	Height of the specified cross section (Y), as a percentage of the field of view. The protective coat will be centered about the location of the cross-section target line.
Depth	Depth of the specified cross section, in microns.
Bulk Mill:	
Number of Cuts	Number of cuts to be made in the bulk mill.
Cross Section:	
Maximum Total Time	As in Deposition group, above.
	Sets the total pattern time for the bulk mill and cross-section patterning. Defect Analyzer uses this value to select the apertures used for bulk milling and cross-sectioning, based on the specified pattern area, depth, and material file.
Y Offset	Displays a horizontal yellow line in the image quadrant, marking the desired upper boundary of the cross section. Click anywhere in the field of view to set the location of this yellow line, then click OK in the accompanying dialog box. For further information, see "Setting Y Offset" on page 4-14.

FIG. 9B

Fiducial Tool Configuration

Scan
Speed
Matrix

	Low	Med	High
Fast	0.028	0.091	0.362
-	0.045	0.181	0.724
-	0.136	0.543	2.173
Slow	0.396	1.584	6.337

Integer 1 ▼

Bitmap: ...

Size (%FOV)

Defect: 40.000000

Fiducial: 10.000000

Size (%FOV)

X: 30.000000

Y: 0.000000

GIS: None ▼

Depth: 1.000000

Configure EBeam Realign

Configure IBeam Realign

Config EBeam BMP Realign

Config IBeam BMP Realign

Apply

Cancel

FIG. 10A

Item	Description
Scan speed matrix	Sets the frame time and resolution used in ion beam and electron beam images collected after milling of the fiducial mark. These images are used for subsequent image recognition.
Integrate	Sets the number of frames to be integrated to allow accumulative noise reduction.
Bitmap	Defect Analyzer converts the specified bitmap to a stream file, based on the grayscale levels of individual pixels in the bitmap. Pixels above the median brightness in the grayscale are omitted from the stream file; pixels below the median brightness are converted to points.
Size (%FOV)	
Defect	Proportion of the field of view to be occupied by the defect.
Fiducial	Size of the fiducial mark, as a percentage of the field of view.
Fiducial Offset From Center (%FOV)	Sets the offset between the center of the image and the center of the fiducial mark, in X and Y, as a percentage of the field of view.
GIS	Selects the GIS to be used in milling the fiducial. The List contains an entry for every beam chemistry available on the system.
Depth	Depth of the fiducial mark, in microns.
Configure EBeam Realign	
Configure IBeam Realign	
Configure IBeam BMP Realign, Configure EBeam BMP Realign	CONFIGURE EBEAM BMP REALIGN and CONFIGURE IBEAM BMP REALIGN configure the image recognition software for initial matches between a fiducial mark and the bitmap used as the milling pattern.

FIG. 10B




FIG. 10C




FIG. 10D




FIG. 10E

Electron Beam Realign Configuration ✕

Train Params | Train Region & Origin | Run Params | Search Region | Graphics | Results

Train Region

Region Mode:
Pixel Aligned Bounding Box Adjust Mask ▼

Region Shape:
CogRectangleAffine ▼

Selected Space Name:
*Use Input Image Space ▼

Select Mode
☒ Origin ☐ Center ☐ 3 Points

Origin X

Origin Y

Screen XLen

Screen Aspect XY

Rotation deg

Skew deg

Train Origin

Selected Space Name:
*Use Input Image Space

Origin X

Origin Y

Screen XLen

Screen Aspect XY

Rotation deg

Skew deg

No train image

FIG. 10F

Electron Beam Realign Configuration ✕									
Train Params		Train Region & Origin		Run Params		Search Region		Graphics	
Results									
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 40%;"> <p>Algorithm:</p> <div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> Best Trained ▼ </div> </div> <div style="width: 60%;"> <div style="display: flex; justify-content: space-between;"> <div> <p>Approx no. to find:</p> <div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1 ▲▼ </div> </div> <div> <p>Accept threshold:</p> <div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 0.5 ▲▼ </div> </div> </div> <div style="margin-top: 5px;"> <input type="checkbox"/> Timeout <div style="border: 1px solid black; padding: 2px; display: flex; align-items: center; margin-left: 20px;"> 50000 ms </div> </div> </div> </div>									
Angle	Nominal		Low		High		Overlap		
Angle	<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 0 ▲▼ </div> deg	◀	<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> -45 ▲▼ </div> deg	◀	<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 45 ▲▼ </div> deg	◀	<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 360 ▲▼ </div> deg		
Scale	<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1 ▲▼ </div>	◀	<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 0.8 ▲▼ </div>		<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1.2 ▲▼ </div>		<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1.4 ▲▼ </div>		
ScaleX	<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1 ▲▼ </div> ms	◀	<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 0.0 ▲▼ </div>		<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1.2 ▲▼ </div>		<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1.4 ▲▼ </div>		
ScaleY	<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1 ▲▼ </div> ms	◀	<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 0.8 ▲▼ </div>		<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1.2 ▲▼ </div>		<div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1.4 ▲▼ </div>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 60%;"> <p><input checked="" type="checkbox"/> Use Pattern Grain Limits</p> <div style="display: flex; justify-content: space-between; margin-top: 10px;"> <div> <p>Compare</p> <div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 4 ▲▼ </div> </div> <div> <p>fine</p> <div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 1 ▲▼ </div> </div> </div> </div> <div style="width: 40%;"> <p>Contrast thresh:</p> <div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 10 ▲▼ </div> <p>XY overlap:</p> <div style="border: 1px solid black; padding: 2px; display: flex; align-items: center;"> 0.0 ▲▼ </div> </div> </div>									
<p style="margin: 0;">No train image</p> <div style="display: flex; justify-content: center; margin-top: 20px;"> <div style="border: 1px solid black; padding: 5px 15px; margin: 0 10px;">OK</div> <div style="border: 1px solid black; padding: 5px 15px; margin: 0 10px;">Cancel</div> </div>									

FIG. 10G

Electron Beam Realign Configuration ✕

Train Params Train Region & Origin Run Params Search Region Graphics Results

Train Region

☐ Show coarse ☐ Show fine

Results

☒ Show origins ☐ Show coordinate axes
☒ Show match regions

Diagnostics

☐ Show match features ☐ Show coordinate axes
☐ Show search region
Note - must re-run the tool to see the effect.

No train image

OK Cancel

FIG. 10H

Cross Section Settings

Beam:	Realign Using Beam Shift:	
<input type="text" value="Electron"/>	<input type="text" value="Yes"/>	

Enable Logging:	Display Match Dialog	Assist Timeout(s):
<input type="text" value="No"/>	<input type="text" value="No"/>	<input type="text" value="0"/>

X Offset:	Y Offset:
<input type="text" value="0.000000"/>	<input type="text" value="0.000000"/>

FIG. 11A

Item	Description
Beam	Specifies the beam to be used in the alignment.
Realign Using Beam Shift	Specifies the type of alignment to be made. YES specifies an alignment made using beam shift. NO specifies an alignment made using a stage move. For best results, realign the electron beam with stage moves and the ion beam with beam shift.
Enable Logging	When this option is selected, the system logs the following information: Name and path of the image file used for realignment X location of the fiducial in pixels and microns Y location of the fiducial in pixels and microns If the fiducial is not found, the system writes "Fail" to the log file.
Display Match Dialog	Displays the Image Match dialogue (see "Image Match" on page 4-10)
Assist Timeout(s)	Number of seconds before a dialog box appears, prompting for user intervention. If this value is 0, no dialog box appears.
FOV Offset	Specifies a proportional shift of the field of view. When this option is selected, the system shifts the field of view by the proportion of the field of view specified in X and Y. When this portion is not selected, the system shifts the field of view by the distance in microns specified in X and Y.
X Offset, Y Offset	Specify the distance by which the system shifts the field of view during alignment. When FIELD OF VIEW is selected, the values specified in X and Y denote a portion of the field of view-e.g., a value of 0.1 equals 10% of the field of view. Acceptable values are 0-1. When FIELD OF VIEW is not selected, the system shifts the field of view by the distance in microns specified in X and Y.

FIG. 11B

EDS Settings


Beam:

☐ Auto CB ☐ Spot Mode Voltage kV

FIG. 12A

Item	Description
Auto CB	Performs automatic contrast and brightness
Spot Mode	Selects Spot as the scanning mode.
Voltage	Voltage to be used to acquire spectrum.

FIG. 12B

*FIG. 12C*

Interface items	Description
Resume	Associates the spectrum with the current site and continues automated processing.
Voltage	Does not put anything into the database and gives you the option to fail the site.

FIG. 12D

Get System Settings		Select All
Set Settings Tool Identifier		Stage
<input checked="" type="radio"/> A	<input type="radio"/> B	<input type="radio"/> C
<input type="radio"/> D	<input type="radio"/> E	<input type="radio"/> F
		<input type="checkbox"/> X Y <input type="checkbox"/> Z
		<input type="checkbox"/> R <input type="checkbox"/> T
Beam Settings		
<input type="checkbox"/> Primary Beam	<input type="checkbox"/> Detector	<input type="checkbox"/> Scan Rotation
Electron Beam		Ion Beam
<input type="checkbox"/> Focus		<input type="checkbox"/> Focus
<input type="checkbox"/> Stig		<input type="checkbox"/> Stig
<input type="checkbox"/> kV		<input type="checkbox"/> Ion Aperature
<input type="checkbox"/> Spot		<input type="checkbox"/> Ion Beam Shift
<input type="checkbox"/> Electron Beam Shift		<input type="checkbox"/> Magnification
<input type="checkbox"/> UHR/Search		<input type="checkbox"/> Contrast/Brightness
<input type="checkbox"/> Magnification		
<input type="checkbox"/> Contrast/Brightness		
Resume		Cancel

FIG. 13A

Item	Description
Select All/De-Select All	Selects or deselects every option in the Stage, Beam Settings, Electron Beam, and Ion Beam groups.
Set Settings Tool Identifier	Identifies a set of stored settings
Stage	Contains options for recording the positions of the five independent axes.
Beam Settings	Contains options for recording the following current beam settings.
Primary Beam	
Detector	
Scan Rotation	
Electron Beam	Contains options for recording the current electron beam parameters. Focus, Stigmation, Accelerating voltage (kV), Spot size, Beam shift, Mode (UHR or Search), Magnification, Contrast/Brightness
Ion Beam	Contains options for recording the current electron beam parameters. Focus, Stigmation, Apperatus, Beam shift, Magnification, Contrast/Brightness

FIG. 13B

Grab Image Settings

☒ E-Beam ☐ I-Beam

Detector
Voltage (kV) ▾

Spot Size ▾

Ion Settings
Aperature ▾

Detector
☒ TLD-S
☐ TLD-B
☐ TLD-C
☐ TLD-D
☐ CDM-E
☐ CEM-I

Mode
☒ UHR
☐ Search

Integrate

Resolution

	Low	Med	High
Fast	0.028	0.091	0.362
-	0.045	0.181	0.724
-	0.136	0.543	2.173
Slow	0.396	1.584	6.337

Integer ▾

Magnification
☐ FOV
☒ Fixed ▾

FIG. 13C

Item	Description
E-Beam	Use electron beam to grab an image.
I-Beam	Use ion beam to grab an image.
Electron Settings:	
Voltage (kV)	Active only for the electron beam. Specify the accelerating voltage.
Spot Size	Active only for the electron beam. Specify the spot size.
Detector	Select the detector used to collect the image. Available selections are dependent on the selected mode and beam. Refer to the xP DualBeam Workstation User's Guide (PN 25417) for information about detector types.
Mode	Active only for the electron beam. Select Search mode for low magnifications and UHR mode for higher magnifications.
Image:	
ACB	Automatically adjusts contrast and brightness using the stored values for comparison.
AutoFocus	Automatically corrects the focus, based on the system sharpness criteria.
AutoStig	Automatically corrects stigmatism, based on the system sharpness criteria. Available for the electron beam.
Data Bar	Save the databar as seen into the image.
Magnification	Specifies the magnification used to grab the image. Select either the field-of-view(determined by the Fiducial tool) or choose from a range of preset magnifications.
Ion Aperture	Active only for the ion beam. Sets the ion aperture.
Resolution	Selects the scan rate and resolution for grabbing a single frame. The values are those available for Grab Image.
Integrate	Specifies the number of collected images to be summed to generate the final image.

FIG. 13D

Pattern Settings

<input type="checkbox"/> Use FOV%	<div>Overlap <input type="text" value="0.00"/> %</div> <div>Dwell <input type="text" value="0.00"/> μs</div> <div>Time <input type="text" value="00:00:00"/> μs</div> <div><input type="checkbox"/> Always Realign</div>	<div>Primary Beam <input checked="" type="radio"/> I-Beam <input type="radio"/> E-Beam</div> <div>Material File <input type="text" value="None"/> ▼</div> <div>Material File <input type="text" value="CleaningCrossSection"/> ▼</div> <div>Rotation <input type="text" value="0.00"/> Degrees</div>
<div>Dimensions X: <input type="text" value="0.00"/> μm Y: <input type="text" value="0.00"/> μm Z: <input type="text" value="0.00"/> μm</div> <div>Center Position X: <input type="text" value="0.00"/> μm Y: <input type="text" value="0.00"/> μm</div>	<div><input type="button" value="Show Pattern"/> <input type="button" value="Apply"/></div>	

FIG. 14A

Item	Description
Use FOV%	Converts X and Y coordinates in Dimensions and Center Position to a percentage of the field of view. When this option is selected X and Y coordinates in Dimensions and Center Position denote a percentage of the field of view. When this option is not selected, X and Y coordinates in Dimensions and Center Position are in microns.
Dimensions	Sets the X, Y, and Z pattern dimensions. When Pattern Type is set to Circle, X and Y are replaced by Rin (inner radius) and Rout (outer radius). Shows the stage X and Y coordinates of the center of the pattern relative to the center of the field of view.
Center Position	
Overlap	
Dwell	Dwell time per pixel. Not available when a material file is selected. Time for milling displayed as either hh:mm:ss or ss:ttt. When this portion is selected, the system always realigns to the fiducial mark before milling the specified pattern. When this option is selected, the system only realigns to the fiducial mark when an aperture has changed or a GIS needle has been inserted.
Time	
Always Realign	
Show Pattern/Remove Pattern	Displays the currently defined pattern. When a pattern is already on screen, removes that pattern.
Primary Beam	Select I-Beam or E-BEAM as the beam that will be used for patterning. Select the material file for your application. Refer to the xP DualBeam Workstation User's Guide (PN 25417) for information about material files. Defines the pattern. Refer to the xP DualBeam Workstation User's Guide (PN 25417) for information about available patterns. Rotates the pattern about its center to the specified angle.
Material File	
Pattern Type	
Rotation	

FIG. 14B




FIG. 15A

Item	Description
Message area	Defines actions the user should take before continuing processing.
Audible alarm	Cause an alarm to sound when the Pause dialog box displays during a job.
Auto dismiss	Selects if the Pause dialog box should time out. Otherwise, the Pause dialog box must be manually dismissed. The number of seconds specifies the fixed amount of time Pause dialog box is displayed during a job.

FIG. 15B




FIG. 15C

Item	Description
Message area	Defines action operator should take before proceeding with the process. The text cannot be modified during runtime.
Timeout clock	The time the dialog box will be displayed during a job. If the operator does not interact with the tool, the Pause dialog box times out as specified and the process automatically continues.
Continue	Click to continue processing the current site. The site list grid will show that the site passed.
Pause/Resume	Stop/restarts the timer. (This button is inactive if AUTO DISMISS was not selected during configuration.) The process waits for the operator to click either CONTINUE or FAIL.
Fail Site	Click to fail the current site. Further processing at the site is aborted. Processing starts at the next site. The site list grid will show that the site failed. If the entire job is to be aborted, the operator can click ABORT in the Run Tool Sequence dialog box

FIG. 15D

Get System Settings

Get Settings Identifier

<input checked="" type="radio"/> A	<input type="radio"/> B	<input type="radio"/> C
<input type="radio"/> D	<input type="radio"/> E	<input type="radio"/> F

Resume Cancel

FIG. 16

Slice and View Settings

Slice

☐ Size of Slices μm

☐ Limit max# of slices to

☐ Number of Slices

Depth μm ☐ Hair Cut

Material File

Max Process Time sec

Metal Deposition

☐ Add Protective Coating

Material File

Pattern Width % of Defect

Pattern Height μm

Image

	Low	Med	High
Fast	0.028	0.091	0.362
-	0.045	0.181	0.724
-	0.136	0.543	2.173
Slow	0.396	1.584	6.337

Integrate

☐ Data Bar ☐ Track Image

☐ ACB ☐ Auto Focus

Field of View: % of X-section

Electron HV and Spot Size

kV Spot

Mode

☐ UHR

☒ Search

Detector

☒ TLD-S ☐ TLD-D

☐ TLD-B ☐ CDM-E

☐ TLD-C ☐ CEM-I

Apply Cancel

FIG. 17A

Item	Description
Slice:	User selects either SIZE OF SLICES or NUMBER OF SLICES.
Size of Slices	Specifies the slice size in microns. The number of slices to be milled will be calculated by dividing the size of the defect (determined by fiducial tool) by the size of the slices.
Limit max # of slices to	The Maximum number of slices to be made in the Slice and View area.
Number of Slices	Specifies the number of slices to be milled. The height of each slice is determined by the software dividing the value specified for height (y) by the number of slices. Where is height from? A maximum of 100 individual patterns can be displayed. If the tool calls for more than 100 slices, an outline indicating the overall area to be sliced is displayed.
Depth	Specifies the pattern depth in microns.
Half Cut	Mills only half way through the defect selected (up to the center cross).
Material File	Displays a dropdown list of selecting a material file (.mtr). The list contains an entry for every material file available on the system. The default material file is si.mtr.
Max Process Time	The Maximum time process may occur
Metal Deposition: Add Protective Coating	If this option is selected, a protective layer will be centered about the Slice and View area. The scale will be set in the job builder configuration and based upon the size of the slice and view area. If protective coating is not selected, the fields associated with it should be inactive.
Material File	Displays a dropdown list for selecting a material file (.mtr). The list contains an entry for every material file available on the system. the default material file is either pt_high mtr.
Pattern Width	Specifies the pattern width, as a percentage of the defect size.
Pattern Height	Specifies the pattern height, in microns.
Image: Scan Speed Matrix	Sets the frame time and resolution used for the electron beam images of the cross-section face. These values correspond generally to the faster continuous scan rates available in xP. Refer to the xP DualBeam Workstation User's Guide for information about the available resolutions.
Integrate	Number of frames to integrate for accumulative noise reductions.
Data Bar	Includes the databar configured in xP in the image.
ACB	Selects automatically adjusting contrast and brightness, using the stored values for comparison.
Track Image	Adjusts the electron beam shaft to keep the face of the cross section centered in the field of view.
Auto Focus	Initiates automated focus before the system begins capturing electron beam images.
Field of View	Specifies the field of view used for electron beam images of the cross-section face, as a percentage of the cross-section.
Electron HV and Spotsizes:	kV specifies the electron beam accelerating voltage, Select from the range of voltages available for the currently selected imaging mode. SPOTSIZE specifies the actual focused area of the electron beam on the sample.
Mode	Select UHR or Search as the imaging mode..
Detector	Select the detector to be used for the electron beam images. Choices are determined by the currently selected imaging mode.

FIG. 17B

Auto Script Settings

Auto Script Settings

Log File Path

FIG. 18A

Item	Description
Script File Path	Name and path of the AutoScript file.
Browser	Accesses the Open dialog box so you can navigate to a script file.
Edit File	Opens the selected script file in the Windows Notepad text editor.
Log File Path	Name and path of the log file.
Browse	Accesses the Open dialog box so you can navigate to the log file.

FIG. 18B

System Settings

Get Current System Settings

Stage

☐ Absolute
☒ Relative

☐ X
☐ Y
☐ Z
☐ R
☐ T

Beam

☐ Primary Beam
☒ Electron
☐ Ion

☐ Magnification

☐ Scan Rotation

Electron Beam

☐ kV
☐ FWD
☐ Spot
☐ Mode
☐ UHR
☒ Search

Ion Beam

☐ Ion Aperture

FIG. 19A

Item	Description
Get Current System Setting	Gets the current system settings for all options.
Stage:	
Absolute	Chooses coordinates measured from the center of the stage.
Relative	Chooses coordinates measured from the current location on the stage
X,Y,Z,R,T	Sets the positions of the five independent axes.
Beam:	
Primary Beam	Sets the ion beam or electron beam as the primary beam. The selected beam sets the magnification and other image data of the current image window.
Magnification	Sets magnification to the specified value.
Scan Rotation	Sets scan rotation to the specified value.
Electron Beam:	Sets scan rotation to the specified value.
kV	Sets the accelerating voltage for the electron beam. Choose a value from the adjacent dropdown list.
FWD	Sets the electron beam focus to the free working distance specified in the adjacent edit box.
Spot	Sets the aperture size for the electron beam. Choose a value from the adjacent dropdown box.
Mode	Selects the mode for the electron beam.
Ion Beam:	
Ion Aperture	Sets the ion beam current to the aperture (inpA) specified in the adjacent dropdown list.

FIG. 19B

ADR Parameters		DThresh Display:	
Die Offset (x-axis)	5000	12	3
<input type="checkbox"/> Center Defect	%FOV Text2	Noise Filter:	
<input type="checkbox"/> Probe Eucentric for Reference Image?		Full	
<input type="checkbox"/> use system state		Electron HV and Spot Size	
<input checked="" type="radio"/> E-Beam <input type="radio"/> I-Beam		1kV	3
Magnification		Ion Aperture	
<input type="radio"/> FOV		3	
<input checked="" type="radio"/> Fixed 2500X			
Detector	Mode	Resolution Med-5.66	
<input checked="" type="radio"/> TLD-S	<input checked="" type="radio"/> UHR	<input checked="" type="checkbox"/> Save Data Bar On Image	
<input type="radio"/> TLD-B	<input type="radio"/> Search	<input type="checkbox"/> ACB	
<input type="radio"/> TLD-C		<input type="checkbox"/> AutoFocus	
<input type="radio"/> TLD-D		<input type="checkbox"/> AutoStig	
<input type="radio"/> CDM-E	Integrate		
<input type="radio"/> CEM-I	1		

FIG. 20A




FIG. 20B




FIG. 21




FIG. 22




FIG. 23A




FIG. 23B




FIG. 24




FIG. 25




FIG. 26A




FIG. 26B




FIG. 27